

Note: The  $\varnothing 30$  holes are for access, we recommend using M10 anchor bolts that will fit into the  $\varnothing 16$  holes.

